| SCHÖNOX Adhesive recommendation - EGGER



Substrate Pi	reparation
--------------	------------

Substrate (for example)	Mastic asphalt screed acc. to DIN EN 13813 (AS)	Cement based screed acc. to DIN EN 13813 (CT) Calciumsulfate- or calciumsulfate flowing screed acc. to DIN EN 13813(CA/CAF)		Dry screed
Primer (for example)	SCHÖNOX SHP (not necessary if sufficient sanding)	SCHÖNOX VD		
Self levelling compound (for example)		SCHÖNOX HS 10 SCHÖNOX HS 10 F SCHÖNOX HS 50		SCHÖNOX HS 10

Floor Covering Installation

Covering/ Collection	Adhesive	Tool/ trowel acc. TKB	Approx. consumption g/m²	Remark
EGGER PRO AQUA+ Laminatboden EGGER HOME AQUA+ Laminatboden	SCHÖNOX® PROTECT Universal adhesive for highest loads	TKB B6 - B11	ca. 800 - 1000 g/m²	Pay attention to adequate wetting of the back of the covering Drying time: approx. 24 hours
EGGER DESIGN-Boden Green TEC	SCHÖNOX® PARKETT 400 Universal wood adhesive for all kind of wood	TKB B3/B6	ca. 800 - 900 g/m²	
	SCHÖNOX® PARKETT 600 waterless universal SMP adhesive with hard glue-line for parquet	TKB B3/B6	ca. 800 g/m²	

Assembly recommendation for private bathrooms

SCHÖNOX® AB SCHÖNOX® FUGENDICHTBAND	SCHÖNOX ® iFIX 2-component, rollable adhesive	Rolle	ca.460 g/m²	
EGGER DESIGN-Boden Green TEC	SCHÖNOX® PARKETT 400 Universal wood adhesive for all kind of wood	TKB B3/B6	ca. 800 - 900 g/m²	
	SCHÖNOX® PARKETT 600 waterless universal SMP adhesive with hard glue-line for parquet	TKB B3/B6	ca. 800 g/m²	

All adhesive fullfill EC1 PLUS acc. to GEV requirements, unless otherwise noted

Please follow the technical information of relevant SCHÖNOX product data sheets, the advices of the manufactures of floor covering and also according to the well-known guidelines and instructions. If in doubt please do some practical tests or call the SCHÖNOX Productservice under phone +02547/910-325. More detailed information, product data sheets or laying instructions are available under www.schoenox.com or www.egger.com.



28.07.2020

| SCHÖNOX Adhesive recommendation - EGGER



